qubit based on $0 - \pi$ Josephson junctions

N. Stefanakis

P.O. Box 1611, 72706, Reutlingen, Germany (Dated: May 20, 2025)

Abstract

We investigate the static properties of $0 - \pi$ Josephson junctions, with particular emphasis on their application in superconducting quantum circuits. Using a theoretical framework based on the sine-Gordon equation, we analyze the phase evolution for $0-\pi$ junctions under various boundary and excitation conditions. These junctions, characterized by spatially varying phase shifts, offer promising configurations for qubit implementations due to their intrinsic symmetry and potential robustness against decoherence. We explore the energy landscape, quantized levels, and switching dynamics relevant for qubit state manipulation. Additionally, we present models for phase, flux, and charge qubit designs, emphasizing their operational principles and readout mechanisms. This work provides insights into the engineering of Josephson-based qubits and supports their continued development as scalable components for quantum information processing.

INTRODUCTION

Superconducting qubits are among the most promising candidates for realizing scalable quantum computers, offering a compelling combination of long coherence times, fast gate operations, and integrability with existing fabrication technologies. At the core of these qubits lies the Josephson junction, a nonlinear superconducting device that exhibits quantum behavior on a macroscopic scale. When embedded in superconducting circuits, Josephson junctions enable the formation of discrete, anharmonic energy levels, essential for isolating two quantum states that define a qubit.

Several types of superconducting qubits have been developed, including the charge qubit, flux qubit, phase qubit, and the transmon qubit—each engineered to balance the competing demands of coherence, control, and scalability [1–3]. These devices exploit the interplay between Josephson energy and charging or inductive energy to create potential wells with discrete energy levels. The ability to perform coherent quantum operations and to read out qubit states with high fidelity has made these systems the foundation of most current quantum computing platforms, such as those developed by IBM, Google, and Rigetti [4].

This work focuses on the static and dynamic properties of Josephson junctions in superconducting qubit architectures, with particular emphasis on $0-\pi$ junctions. These junctions, which incorporate phase discontinuities, offer unique properties for qubit stability and may play a crucial role in minimizing decoherence and improving gate performance [5, 6]. By modeling the quantum dynamics and potential profiles of these junctions, we aim to elucidate the underlying mechanisms that govern qubit behavior and to identify design strategies for optimized quantum hardware.

JOSEPHSON EFFECT FOR $0 - \pi$ JUNCTION

We describe the junction with width w small compared to λ_J in the y direction, of length L in the x direction, in external magnetic field H in the y direction as shown in Fig. 1. The intrinsic phase difference $\theta(x)$ is ϕ_{c1} in $0 < x < \frac{L}{2}$ and ϕ_{c2} in $\frac{L}{2} < x < L$, where $\phi_{c_1} = \phi_{c_2} = 0$ for a 0 - 0 junction and $\phi_{c_1} = 0$, $\phi_{c_2} = \pi$ for a $0 - \pi$ junction. The superconducting phase difference ϕ across the junction is then the solution of the Sine-Gordon equation

$$\frac{d^2\phi(x)}{dx^2} = \frac{1}{\lambda_J^2} \sin[\phi(x) + \theta(x)],\tag{1}$$

with the inline boundary condition

$$\frac{d\phi}{dx}|_{x=0,L} = \pm \frac{I}{2} + H \tag{2}$$

The Josephson penetration depth is given by

$$\lambda_J = \sqrt{\frac{\hbar c^2}{8\pi e d\widetilde{J}_c}}$$

where d is the sum of the penetration depths in two superconductors plus the thickness of the insulator layer. We also assume that \tilde{J}_c is constant within each segment of the interface.

We compute the free Energy

$$F = \frac{\hbar \widetilde{J}_c w}{2e} \int_0^L \left[1 - \cos\left[\phi(x) + \theta(x)\right] + \frac{\lambda_J^2}{2} \left(\frac{\partial \phi}{\partial x}\right)^2 \right] dx,\tag{3}$$

Solving the corresponding Schrodinger equation we can obtain the quantized energy levels. Due to the $cos\phi$ dependence, the potential Energy is an-harmonic and the energy level splittings are unequal unlike the equal energy level splitting of the Single harmonic oscillator or a superconducting LC circuit. In Josephson junction the lowest energy levels can be addressed by using external excitation of energy $\hbar\omega_{01}$ between $|0\rangle$ and $|1\rangle$.

THEORY

Phase qubit

The phase qubit is a current-biased Josephson junction without any shunt capacitor or inductor. The circuit can be considered by a current source, I, applied to a junction capacitance C_J in parallel with a suprecurrent $I_0 \sin \phi$. The potential energy is given by

$$U(\phi) = -E_J(\cos\phi + I\phi/I_0)$$
(4)

where $E_J = \frac{\hbar I_0}{2e} = \frac{I_0 \Phi_0}{2\pi}$. This is an anharmonic potential. The energy levels in the potential well can be obtained by solving the Schrodinger equation. The bias current I can be adjusted so that only two energy levels are inside the well. A microwave ac current can be used to drive oscilations between the states $|0\rangle$ und $|1\rangle$ forming a qubit. The possibility of MQT switching to the resistive state is higher for the state $|1\rangle$. This makes possible to read the state of the qubit.

Flux qubit

The flux qubit is based on currents induced by an external magnetic field applied to a superconducting loop containing a Josephson junction. The potential energy is given by

$$U(\phi) = -E_J \cos(2\pi \frac{\Phi}{\Phi_0}) + \frac{(\Phi - \Phi_e)^2}{2L}$$
(5)

 $U(\Phi)$ is a parabola modulated by a sinusoidal. Only the lowest energy in each well is important. When $\Phi_e > \Phi_0/2$ then the right potential well has lower energy favoring a counter clockwise circulating current that pushes the total flux to Φ_0 . When $\Phi_e < \Phi_0/2$ then the left potential well has lower energy favoring a clockwise circulating current that pushes the total flux to 0. When $\Phi_e = \Phi_0/2$ the energy levels are resonant. This correspond to a superposition of clockwise an counterclockwise supercurrent flowing simultaneously in the circuit. The degenerate energy levels at $\Phi_e = \Phi_0/2$ become coupled by quantum tunneling through the potential barrier between the two states. As a result of this coupling the degenerate energy levels are split. A superposition of clockwise and counter-clockwise suprecurrent arises in the circuit.

Charge Qubit

The charge qubit, also known as the Cooper pair box, is a fundamental superconducting qubit architecture that utilizes the quantization of charge on a superconducting island connected to a reservoir via a Josephson junction. The system is controlled through a gate voltage applied via a gate capacitor, which allows precise tuning of the energy levels.

The Hamiltonian of the charge qubit is given by

$$H = 4E_C(n - n_g)^2 - E_J \cos\phi, \qquad (6)$$

where $E_C = \frac{e^2}{2C_{\Sigma}}$ is the charging energy, E_J is the Josephson energy, n is the number of excess Cooper pairs on the island, $n_g = \frac{C_g V_g}{2e}$ is the dimensionless gate charge, and ϕ is the superconducting phase difference across the junction.

The first term in the Hamiltonian represents the electrostatic energy due to the charge on the island, while the second term accounts for the tunneling of Cooper pairs through the Josephson junction. The interplay between these two energies allows the system to be operated as a quantum two-level system when biased near a degeneracy point $(n_g = 0.5)$, where the energy levels are split due to tunneling and form an avoided crossing.

At this operating point, often referred to as the "sweet spot," the qubit becomes less sensitive to charge noise, improving coherence properties. By applying microwave pulses at the qubit transition frequency, coherent oscillations (Rabi oscillations) can be induced between the ground and excited states, enabling qubit control.

Readout of the qubit state is typically achieved using a nearby charge sensor such as a single-electron transistor (SET), which detects the change in charge state of the qubit island. The Josephson energy E_J can be made tunable by replacing the junction with a DC-SQUID, allowing additional control over the qubit dynamics.

RESULTS

In this section we solve numerically Eq. 1 for different junction lengths and compute the Free Energy of the solutions.

Flux qubit

We study first the case where the external current is 0 and the magnetic field is modulated.

We consider first the 0 - 0 junction. We plot in Fig. 2 the Free energy as a function of the Flux Φ for the long length limit L = 10. We see that the Free energy corresponding to the different modes is a continuous function of the Flux.

We consider then the case of a $0 - \pi$ junction. We plot in Fig. 3 the Free energy as a function of the Flux Φ for the long length limit L = 10. In contrast to the 0 - 0 case we see that here the different modes are overlapping. The system can be prepared to the state with flux 0.5 corresponding to the fractional vortex fv or to the state with flux -0.5corresponding to the fractional anti-vortex fav. Note that for zero Flux the energy levels of the fv and fav are resonant or degenerate. This corresponds to a superposition of fv and fav that appear simultaneously in the circuit.

The degenerate energy levels at $\Phi = 0$ become coupled by quantum tunneling through the potential barrier between these states. This potential barrier is proportional to the E_J . As a result of this coupling, the degenerate energy levels are split. These energy levels correspond to the new eigenstates of symmetrical $|-\rangle = \frac{1}{\sqrt{2}}(fv + fav)$ and anti-symmetrical $|+\rangle = \frac{1}{\sqrt{2}}(fv - fav)$ superposition states of the fractional vortex and antivortrex respectively.

In the small junction limit L = 1 for the 0-0 junction the Energy is a continuous function of the magnetic flux as we see in Fig. 4 while for the $0-\pi$ case the two modes corresponding to the fractional vortex and antivortex have their minimum at flux different than zero (see Fig. 5) but not at ± 0.5 . The same discussion als in the large junction limit applies here with the zero flux point to be considered as a resonant state between the fv and fav states. The possibility of quantum Tunneling here is larger due to the small potential barrier.

Phase qubit

We study now the case where the external current is modulated and the magnetic field is zero. This case corresponds to a charge qubit.

For the 0 - 0 junction and L = 10 we plot in Fig. 6 the Energy versus the external current for the mode 0 - 1 that exists in this limit. Here the Energy is zero for zero current.

For the case of $0 - \pi$ junction on the other hand as we see in Fig. 7 the minimum of the Energy is not zero and solutions exist for all the flux modes that exist in that limit. Note here that the modes corresponding to the fractional vortex and anti-vortex coincide.

Finally we consider the small 0 - 0 junction in the limit l = 1. The plot in Fig. 8 the Energy as a function of the current for zero flux. The evolution of the free energy is similar to the large junction limit.

CONCLUSIONS

In this work, we have examined the static behavior of Josephson junctions, with a particular focus on their relevance to superconducting qubit implementations. By analyzing $0-\pi$ junctions and solving the sine-Gordon equation under appropriate boundary conditions, we have characterized the phase evolution, and energy landscape of these systems. Our results demonstrate how the intrinsic phase discontinuity in $0-\pi$ junctions can give rise to localized modes and anharmonic potentials suitable for qubit encoding.

Furthermore, we have outlined the operating principles of various types of superconducting qubits—including phase, flux, and charge qubits—emphasizing how different configurations of Josephson junctions can be exploited for coherent quantum state manipulation and readout. The theoretical framework provided here offers a basis for optimizing qubit designs in terms of coherence time, control fidelity, and scalability.

Overall, this study contributes to the understanding of Josephson-based quantum circuits and supports their development as a leading technology platform for quantum computing. Future work will benefit from extending this analysis to multi-junction systems and incorporating environmental noise effects to evaluate decoherence mechanisms more precisely.

- [1] Ray LaPierre, "Introduction to quantum computing", Springer 2021.
- [2] J. Clarke and F. K. Wilhelm, "Superconducting quantum bits," Nature, vol. 453, no. 7198, pp. 1031–1042, 2008.
- [3] M. H. Devoret and R. J. Schoelkopf, "Superconducting circuits for quantum information: An outlook," Science, vol. 339, no. 6124, pp. 1169–1174, 2013.
- [4] M. Kjaergaard et al., "Superconducting Qubits: Current State of Play," Annual Review of Condensed Matter Physics, vol. 11, pp. 369–395, 2020.
- [5] Guo-Liang Guo, Han-Bing Leng, Yong Hu and Xin Liu, "0-π qubit in one Josephson junction", Phys. Rev. B vol. 105, pp. L180502, 2022
- [6] Sunmi Kim, Leonid V. Abdurakhimov, Duong Pham, Wei Qiu, Hirotaka Terai, Sahel Ashhab, Shiro Saito, Taro Yamashita and Kouichi Semba, "Superconducting flux qubit with ferromagnetic Josephson π-junction operating at zero magnetic field", Commun Mater vol. 5, pp. 216 2024



FIG. 1. The Josephson junction of length L.



FIG. 2. Energy of a 0 - 0 junction of lenth l = 10 versus the magnetic flux Φ . The different modes correspond to different values of the magnetic flux



FIG. 3. Energy of a $0 - \pi$ junction of length l = 10 versus the magnetic flux Φ . The different modes correspond to different values of the magnetic flux



FIG. 4. Energy of a 0 - 0 junction of length l = 1 versus the magnetic flux Φ .



FIG. 5. Energy of a $0 - \pi$ junction of length l = 1 versus the magnetic flux Φ . The different modes correspond to different values of the magnetic flux



FIG. 6. Energy versus current for a 0-0 junction of length l = 10



FIG. 7. Energy versus current for a $0 - \pi$ junction of length l = 10



FIG. 8. Energy versus current for a 0-0 junction of length l=1